



INSTRUCTIONS FOR INSTALLATION

INCLUDED PARTS

- Back-to-back shower door pulls
- 2 - Threaded mounting bolts
- 4 - Washers
- 2 - Jam nuts
- 2 - Set screws



INSTRUCTIONS

1. Loosen set screws to separate handles. See diagram for set screw placement.
2. Unscrew the threaded mounting bolts, set aside and discard the plastic spacers.
3. Refer to glass door manufacturer's instructions for drilling the 5/16" handle holes.
4. Insert the threaded mounting bolt (with jam nut and washer in place as shown in diagram) in top hole from the inside of the glass door. Place washer on mounting bolt and tightly screw threaded mounting bolt into outside handle top hole.

NOTE: The "outside" handle does NOT have the set screw.

5. Repeat step three for bottom hole.
6. Slide the inside handle over the mounting bolts. Secure by tightening the set screws.

CARE

Clean only with a soft, dry cloth. To protect the finish, we do not recommend the use of polishes or abrasives. If you have any questions regarding your Vicenza Designs product, please contact your local dealer.

